

REPLACEMENT PADS INSTRUCTIONS

STEP 1.

PEEL OFF THE OLD PADS

Begin by peeling off the old pads by lifting the corner edge of each pad.



STEP 2.

REMOVE ANY LEFTOVER ADHESIVE RESIDUE

There will be an adhesive residue left behind. Put a small amount of nail polish remover (acetone) on a paper towel and gently rub off the adhesive residue.

Warning: *Be careful that the nail polish remover doesn't make contact with the Vinyl Vac label or it may bleed the colors of the label.*



STEP 3.

APPLY THE NEW PADS TO THE VINYL VAC

Peel the back off the new pads and adhere them to the Vinyl Vac. Place each pad just over the edge of the intake on each side. Press each pad down firmly.

